

PILOT™ SEATING

Operating Instructions



Deriving Maximum Benefit From Your Pilot™ Task Chair

A. Back Angle Adjustment

Hold the lever up to change the back angle; drop the lever to lock the back angle.

B. Seat Height Adjustment

To lower the seat - remain seated in chair and raise the lever.

To raise the seat - lift body weight slightly off the chair and raise the lever.

C. Tilt Lock Adjustment

Raise the lever to allow seat and back to rock; drop the lever to prevent movement.

D. Back Height Adjustment

To raise the back - grasp the lower edge of the back and raise the back to the desired height.

To lower the back - first raise the back to its uppermost limit and then allow the back to fall to its lowest limit.

E. Seat Depth Adjustment

Lift or hold lever up for movement; release the lever to lock the seat depth.

F. Tilt Tension Adjustment

Turn the knob clockwise to increase tension and counterclockwise to decrease tension.

