

RANGE TASK SEATING

RANS (Stool)
Chair Operating Instructions



1. Lumbar

2. Back Height

3. Back Angle

4. Seat Height

5. Arm Height & Pad

6. Arm Width

7. Foot Ring Height

RANGE TASK SEATING

RANS (Stool) Chair Operating Instructions

1. Lumbar

Adjust the lumbar by turning the knob clockwise for more support or counterclockwise for less support.

2. Back Height

Rotate the knob in a counterclockwise motion, lift back up to the desired height and tighten the knob by turning clockwise. To lower the back height, rotate the knob in a counterclockwise motion, lower the back to the desired height and tighten the knob by turning clockwise.

3. Back Angle

To adjust the backrest angle, lift the paddle up lean back to the desired position. Release the paddle to lock in position.

4. Seat Height

Lift the paddle up and simultaneously lift your weight from the seat while raising or lowering the seat. Release the lever to lock the seat in position.

5. Arm Height & Pad

Depress and hold the button on the side of the arm and lift or lower to desired height. Arm pads can slide forward and backward and side to side, as well as pivot inward.

6. Arm Width

To adjust the arm width, loosen the knob found under the seat, move the arm to the desired width and tighten the knob to lock in place.

7. Foot Ring Height

To adjust foot ring height, loosen ring by turning counterclockwise then raise or lower to desired height. To set in place, turn clockwise until tight.

